

Instructions:

1. Print out this .pdf at 1:1 scale (zoom 100%).
2. Verify the printout by using a ruler against the 6" or 150mm marks, a US Dollar Bill against the dollar mark, or a €20 note against the €20 mark. If the marks are not close, check printer settings and try again.
3. Cut out scale.
4. Trim scale to Start line.
5. Wrap scale around tube.
6. Burnish where scale overlaps Start Line (a pencil or even a fingernail will make a nice mark).
7. Note the nearby tubing diameter line. Your mark should come close to one of the tubing diameter lines. If it's far from any line, it is probably an unusual size. It would be best to double check with a caliper or other measuring tool.

